



Wymiary prowadnic




	A	250	300	350	400	450	500	550	600
A		250	300	350	400	450	500	550	600
B		192±2	268±2	343±2	382±2	452±2	503±2	550±2	600±2

Wypinanie prowadnicy



Mocowanie prowadnic do korpusu



Mocowanie prowadnic do szuflady

